




Intermec



Spare Parts Catalog

**EasyCoder PD4
Bar Code Label
Printer**

Intermec Technologies Corporation
Corporate Headquarters
6001 36th Ave. W.
Everett, WA 98203
U.S.A.
www.intermec.com

The information contained herein is proprietary and is provided solely for the purpose of allowing customers to operate and service Intermec-manufactured equipment and is not to be released, reproduced, or used for any other purpose without written permission of Intermec.

Information and specifications contained in this document are subject to change without prior notice and do not represent a commitment on the part of Intermec Technologies Corporation.

© 2005 by Intermec Technologies Corporation. All rights reserved.

The word Intermec, the Intermec logo, Norand, ArciTech, CrossBar, Data Collection Browser, dcBrowser, Duratherm, EasyCoder, EasyLAN, Enterprise Wireless LAN, EZBuilder, Fingerprint, i-gistics, INCA (under license), InterDriver, Intermec Printer Network Manager, IRL, JANUS, LabelShop, Mobile Framework, MobileLAN, Nor*Ware, Pen*Key, Precision Print, PrintSet, RoutePower, TE 2000, Trakker Antares, UAP, Universal Access Point, and Virtual Wedge are either trademarks or registered trademarks of Intermec Technologies Corporation.

Throughout this manual, trademarked names may be used. Rather than put a trademark (™ or ®) symbol in every occurrence of a trademarked name, we state that we are using the names only in an editorial fashion, and to the benefit of the trademark owner, with no intention of infringement.

There are U.S. and foreign patents pending.

Contents

1 Introduction

Spare Parts Policy	2
EasyCoder PD4 (no display), General View	3
EasyCoder PD4 (with display), General View	4

2 Spare Parts

Panel Module, Left (no display)	6
Panel Module, Left (with display)	7
Panels, Right Hand Side.....	8
Print Unit Parts.....	9
Thermal Printhead Module	10
Label Gap Sensor Module	11
Motor Module	12
Belt Tension Spring.....	13
Ribbon Module.....	14
Ribbon Out Sensor	15
Ink Position Knob.....	16
Edge Guide Kit.....	17
Main Board.....	18
Switching Power Module	19
Power Switch.....	20
Memory Expansion Card	21
Cutter	22
Rewinder	23
Miscellaneous, not illustrated	24



1 Introduction

This chapter contains the Intermec Spare Parts Policy regarding printers and provides an overview of the various EasyCoder PD4 models with options.

Spare Parts Policy

This Spare Parts Catalog contains information on items presently available as spare parts and accessories for the Intermec EasyCoder PD4 printers.

You will notice that, as a rule, we supply only assembled spare parts. Our policy is based on the conviction that this is a more rational way of stocking spares and supplying adequate service as well.


For further information about parts not listed in this volume, please contact our Spare Parts Sales Department.

Information in this manual is subject to change without prior notice and does not represent a commitment on the part of Intermec.




Note: For updated information, please refer to the latest edition of the Spare Parts Price List.

EasyCoder PD4 (no display), General View




Pos.	Description	Remarks
1	Panels, Right Hand Side	See page 8
2	Panel Module, Left	See page 6
3	Panel, Bottom Right	See page 8
4	Print Mechanism	See pages 9-13
5	Transfer Ribbon Mechanism	See pages 14-16
6	Edge Guides	See page 17
—	Main Board	See page 18
—	Switching Power Module	See page 19
—	Power Switch	See page 20

EasyCoder PD4 (with display), General View




Pos.	Description	Remarks
1	Panels, Right Hand Side	See page 8
2	Panel Module, Left	See page 7
3	Panel, Bottom Right	See page 8
4	Print Mechanism	See pages 9-13
5	Transfer Ribbon Mechanism	See pages 14-16
6	Edge Guides	See page 17
—	Main Board	See page 18
—	Switching Power Module	See page 19
—	Power Switch	See page 20
—	Memory Expansion Board (option)	See page 21
—	Cutter (option)	See page 22
—	Rewinder (option)	See page 23



2 Spare Parts


This chapter shows the various spare parts and lists their part numbers. The text in the description field is selected to help understanding the purpose of the part and is not necessarily the same as the text on drawings, packing slips, and invoices.

Panel Module, Left (no display)




Pos.	Part No.	Description	Remarks
1	073948-001	Panel Module, w/o LCD, left PD4	Complete unit
2	074053-001	Cable	Display to Main board

Panel Module, Left (with display)




Pos.	Part No.	Description	Remarks
1	073955-001	Panel Module, with LCD, left PD4	Complete unit incl. strip sensor
2	074054-001	Cable	Display to Main board
3	073957-001	Strip Sensor Module/PD4	Incl. cable

Panels, Right Hand Side




Pos.	Part No.	Description	Remarks
1	074055S-001	Right-hand door	Complete unit incl. hinges
2	073951-001	Panel, Top Right/PD4	
2	074056-001	Panel, Bottom Right/PD4	

Print Unit Parts




Pos.	Part No.	Description	Remarks
1	074070-001	Pulley 200 dpi	
1	074071-001	Pulley 300 dpi	
2	074068-001	Media Guide, inner	
3	074067-001	Media Guide, outer	
4	073954-001	Platen Module/PD4	
5	074073-001	Headlift Sensor	Incl. cable

Thermal Printhead Module




Pos.	Part No.	Description	Remarks
1	073959-002	TPH Module 200 dpi/PD4	
1	073961-002	TPH Module 300 dpi/PD4	

Label Gap Sensor Module




Pos.	Part No.	Description	Remarks
1	073952-001	Sensor, Label Module/PD4	Complete unit incl cables

Motor Module




Pos.	Part No.	Description	Remarks
1	073950-001	Motor Module	Complete unit (200 & 300 dpi)
2	074057-001	Belt (200 dpi)	
2	074059-001	Belt (300 dpi)	

Belt Tension Spring




Pos.	Part No.	Description	Remarks
1	074075-001	Belt Tension Spring	

Ribbon Module




Pos.	Part No.	Description	Remarks
1	073947-001	Ribbon Module/PD4	Complete unit incl. belt and bobbin plates
2	074058-001	Belt	
3	074072-001	Bobbin Plate	Screw not included

Ribbon Out Sensor




Pos.	Part No.	Description	Remarks
1	073953-001	Sensor, Ribbon Out, Module/PD4	Incl. cable

Ink Position Knob




Pos.	Part No.	Description	Remarks
1	074077S-001	Ink Position Knob	

Edge Guide Kit



Pos.	Part No.	Description	Remarks
1	074064S-001	Edge Guide Kit	Two complete edge guides (high & low)


Main Board



1


Pos.	Part No.	Description	Remarks
1	073960-001	PCB Main Module/PD4/no display	Not illustrated
1	073958-001	PCB Main Module/PD4 200 dpi	Illustrated
1	073962-001	PCB Main Module/PD4 300 dpi	Not illustrated

Switching Power Module




Pos.	Part No.	Description	Remarks
1	073949-001	Switching Power Module/PD4	Complete unit

Power Switch



Pos.	Part No.	Description	Remarks
1	073956-001	Power Switch Parts, Kit/PD4	Incl. cables


Memory Expansion Card



1


Pos.	Part No.	Description	Remarks
1	073963	Memory 2M Card/PD4	2MB Flash Memory

Cutter



Pos.	Part No.	Description	Remarks
1	073964	Cutter Module/ABS-P/PD4	Complete Unit
2	074062-001	Cutter PCB	Incl. cable
3	074061-001	Plastic Moulding	
4	074063-001	Tray	

Rewinder



Pos.	Part No.	Description	Remarks
1	073965	Rewinder Module, internal/PD4	
2	074074-001	Liner Takeup Full Sensor	Incl. cable
3	074060-001	Liner Retention Clip	
–	074076-001	Rewind Drive Belt	Not illustrated

Miscellaneous, not illustrated

Pos.	Part No.	Description	Remarks
–	1-110501-00	Cleaning Card 25-pack	
–	074065S-001	Fastener Kit for PD4 w/o display	Assorted screws, washers, and clips
–	074066S-001	Fastener Kit for PD4 with display	Assorted screws, washers, and clips



Intermec Technologies Corporation

Corporate Headquarters
6001 36th Avenue West
Everett, WA 98203
U.S.A.

tel +425.348.2600

fax +425.355.9551

www.intermec.com

EasyCoder PD4, Spare Parts Catalog



1-960617-01